

Heat Press Settings (Transfer Printing, including DTF and HTV)

- 165 degrees
- 25 seconds
- Medium pressure (32-36 PSI)
- When pressing jute, you need to keep the two laminated sides from touching. Do this by inserting a silicon sheet inside the bag, separating the sides
- Cover the surface with a Teflon sheet
- Leave the transfer to cool before removing the backing paper. It helps with adhesion on jute

Ink Advisories (Screen Printing)

- Due to the raw/natural fibres we recommend using a water based ink for printing onto jute
- Water-based ink will soak further in, making it less likely to crack or scrape off an uneven surface
- If printing on laminated Jute, ink may collect in the gaps between the open weave. This may require longer curing
- If printing on laminated ensure inside of bag is separated during curing, to prevent them becoming tacky and sticking together

Embroidery Advisories

- Size 16/100 needle advised for this weight fabric